

---

## MANUFACTURER'S MATERIAL SAFETY DATA SHEET

---

### SECTION I – PRODUCT AND COMPANY IDENTIFICATION

---

#### Product identification

Product Name : Direct Reduced Iron (DRI)  
Trade Name : DRI Pellets/Lump  
Chemical Name : Iron  
Product Use : Iron and Steel Production

Proper Shipping Name : Direct Reduced Iron (B), Pellets,  
IMO Class : MHB  
Group : B  
BC (Bulk Cargo) No : 015  
MFAG table NO : None  
EmS NO : BC 15  
Approx. Stowage Factor : 0.5 M<sup>3</sup> / T

#### Company Identification

Manufacturer's Name : Qatar Steel Company (QSC)

Address: PO Box 50090  
Mesaieed Industrial City  
Mesaieed  
State of QATAR

Phone Numbers : + 974 4778778  
FAX Numbers : + 974 44771424

---

## SECTION II – HAZARD(s) IDENTIFICATION

---

Class : Not classified as Hazardous

Ingredients : No known hazardous ingredients

Poison schedule : Not scheduled.

### HEALTH EFFECTS

Acute Ingestion : If swallowed, dust or small pieces may cause gastrointestinal disturbances. An overdose of iron may cause irritation to the mouth and stomach. Symptoms may include nausea, vomiting and abdominal pain.

Eye Contact : Dust and small pieces may cause mechanical irritation, redness and pain in contact with the eyes.

Skin contact : Dust and small pieces may cause mechanical irritation in contact with the skin, which can result in slight redness.

Excessive Inhalation : Inhalation of dust may cause irritation to the respiratory tracks. Symptoms may include coughing, sneezing, soreness of throat and breathing difficulties.

---

### SECTION III – Composition/ information on Ingredients

---

CHEMICAL DATA: (Percentages by weight)

|                     |   |                  |
|---------------------|---|------------------|
| Total Iron (TFe)    | : | <b>91% Min</b>   |
| Metallic Iron (MFe) | : | <b>85% Min</b>   |
| Carbon (C)          | : | <b>2.2% Min</b>  |
| Sulfur (S)          | : | <b>0.01% Max</b> |
| Phosphorous (P)     | : | 0.06 % Max       |
| Total Gangue        | : | 4.8 % Max        |

---

### SECTION IV - FIRST AID MEASURES

---

#### FIRST AID

|                      |   |   |
|----------------------|---|---|
| If swallowed         | : | Induce vomiting immediately. Seek medical attention.  |
| Inhalation           | : | Remove person to fresh air. Get medical attention in case of breathing difficulty.  |
| Eyes                 | : | If contact with eye(s) occurs wash with copious amount of water for approximately 15 minutes. If eye irritation develops and persists seek medical attention.   |
| Skin                 | : | Wash gently and thoroughly with water and soap. Ensure contaminated clothing is washed before re-use or discard. If irritation develops seek medical attention. |
| First Aid facilities | : | Eye wash and normal washroom  |

---

---

## SECTION V – FIRE FIGHTING MEASURES

---

### FIRE AND EXPLOSION HAZARD DATA

Material may slowly evolve hydrogen after contact with water and reacts more rapidly with sea/ salt water. Maximum allowable ship loading temperature is 65 ° C. if temperature exceeds 65 ° C, provide adequate ventilation to remove any hydrogen gas generation.

#### Firefighting procedures

Remove the hot material from the stack. Divide hot material into small piles and spread it out. The materials will cool below the ignition point. In case, if it is not practical to spread the material over a wide area such as in a hold of a ship, covering by a non oxidant material like sand / finely crushed slag could be used for smothering the fire and hindering the air supply.

Do not use seawater to cool and avoid fresh water also to cool down the hot material. In case if fresh water is used,

- i) use large amount of water to flood the material and
- ii) Provide adequate ventilation to let hydrogen gas generated escape to atmosphere.

Ignition temperature : Above 125 ° C.

Special firefighting procedures : Divide into small piles and flood with water. Do not use CO<sub>2</sub> Extinguisher as CO may be formed.

Unusual Fire and explosion Hazards : Product is porous iron which rusts in the presence of water and air. Rusting creates heat which may cause large piles to heat up and ignite. Hydrogen gas also is liberated from wet product. If piles become hot, separate into small piles and flood with water.

---

## SECTION VI – ACCIDENT RELEASE MEASURES

---

|                                    |  |
|------------------------------------|--|
| Steps to be taken in case of spill | : DRI pellets roll. Care must be taken when walking on it. Practice good Housekeeping procedures.            |
| Material in Bulk                   | : Broken pieces and dust generated during loading and unloading should be collected and disposed adequately. |

---

## SECTION VII - HANDLING AND STORAGE

---

Store in cool, dry area removed from oxidizing agents, flammable materials and other sources of heat.

Storage bins and silos must be inerted with seal gas or Nitrogen so that oxygen concentrations are below 4%. Avoid wet DRI storage in bins and silos.

Prior to shipment, DRI should be aged at least for 72 hours, or treated with some other equivalent passivation technique. The pile temperature has to be measured at frequent intervals by inserting thermocouple in each pile.

It should not be loaded if temp. is  $> 65^{\circ}\text{C}$ . No wet material to be loaded, it should be under dry condition, although discharge under all weather conditions is acceptable.

The cargo should be evenly distributed & concentrations of fines minimized, cargo should be loaded in layers, each of nominal height of 2 meters, to assist fine distribution.

Boundaries of compartments where DRI is carried should be resistant to fine & passage of water, Hatch covers should be inspected & tested. They should remain sealed throughout the Voyage.

It is important that the Vessel's Ventilation system is fully operational.

All cargo space should be clean & dry, wooden fixtures should be removed.

---

## SECTION VIII – EXPOSURE CONTROLS, PERSONAL PROTECTION

---

|                        |   |  |
|------------------------|---|--|
| Respiratory Protection | : | During handling dust is generated and respiratory protection of EN 149:2001 may be used.                 |
| Eye Protection         | : | During handling – loading and unloading, use Safety Spectacles as dust evolution and chips may be there. |
| Other Protection       | : | Safety Helmet, Safety Shoes and Cotton hand gloves.  |

---



---

## SECTION IX – PHYSICAL AND CHEMICAL PROPERTIES

---

|                                |   |                |
|--------------------------------|---|----------------|
| Physical State                 | : | Solid          |
| Appearance                     | : | Light grey     |
| Odor                           | : | Odorless       |
| Apparent Density g/cc          | : | 3.5 +/-        |
| Bulk Density MT/M <sup>3</sup> | : | 1.8 +/-        |
| Porosity- %                    | : | 35 +/-         |
| Water Pick-up %                | : | 12 +/-         |
| Dimension                      | : | 6 – 30 mm      |
| Volume                         | : | 2 cc           |
| Weight                         | : | 0.5 g          |
| Solubility in water            | : | Insoluble      |
| Flash Point                    | : | Not Applicable |
| Flammability – LEL             | : | Not Applicable |
| - UEL                          | : | Not Applicable |

---

## SECTION X - STABILITY AND REACTIVITY DATA

---

|                     |   |  |
|---------------------|---|--|
| Stability           | : | Stable under normal conditions.<br>Unstable when wet, oxidizes with fresh water and more readily with sea water forming rust and generation of Hydrogen Gas. |
| Conditions to avoid | : | Temperature above 65 °C<br>Contact with acid, open flame and water.  |

---

---

## SECTION XI – TOXICOLOGICAL INFORMATION

---

No toxicity data available

---

---

## SECTION XII – ECOLOGICAL INFORMATION

---

DRI is not considered to be a contaminant to the environment.  
Proper dust treatment or collection system to be there for the DRI dust generated during handling, loading and unloading.  
Avoid spillage in land or water.  
Local environmental regulations shall be followed.

---

---

## SECTION XIII – DISPOSAL CONSIDERATION

---

|                |  |
|----------------|--|
| Waste Disposal | Recycle all the spillage possible.<br>Dust shall be collected, treated, recycled / disposed off as per the prevailing environmental regulations. |
|----------------|--|

---

## SECTION XIV – TRANSPORT INFORMATION

---

Surface transportation  
(Road & rail)

Local transportation regulations shall be followed.

### Maritime Transport

DRI is classified by International Maritime Organization in the BC code as “Material Hazardous in Bulk” (MHB).

As per IMO a “Competent Authority” is to certify that the Vessel is Safe enough for Carrying DRI Material.

“Competent Authority” is a person recognized by National Administration of the Country of Shipment who should certify to the Ship’s Master that the DRI, at the time of loading, is suitable for shipment.

Before commence loading “Competent Authority” inspects the Vessel & his team (Supercargo & Loading Supervisor) to check any seepage from the bottom & dry conditions of holds.

Then all hatch covers are closed & water is sprayed for checking any leakage from top. Then “Competent Authority” will issue NOC for loading.

Supercargo is a person to do all critical parameters checking (temp, O<sub>2</sub> & H<sub>2</sub>) every 8 hours & relays information to the master & shipper daily through Vessel’s communication system during Voyage.

Throughout the Voyage, cargo spaces are to be maintained under an inert atmosphere containing < 5% O<sub>2</sub>. Inert gas should be N<sub>2</sub> & not CO<sub>2</sub> which under reaction with hot iron would generate dangerous CO.

H<sub>2</sub> content of atmosphere should be maintained below 1%. Monitoring of O<sub>2</sub> & H<sub>2</sub> should be carried at regular interval.

In case H<sub>2</sub> exceeds 1%, the hatch should be ventilated until it is reduced to below 1%.



The temp. of the Cargo should be monitored at regular intervals during voyage. Before loading the Cargo, the floor of each hatch should be wired with thermocouples at a specific places. Second layer of thermocouples should be placed after loading half of the Cargo.

In case Cargo temp. exceeds 200 ° C, Ship must be headed to nearest port, if cannot reached swiftly, flooding of hatch could be the last solution with fastest rate of water input.

Cargo spaces carrying DRI may become Oxygen-depleted, caution should be exercised when entering such compartment.

Radar & RDF Scanners should be protected from dust during loading & discharging Operations.

---

## SECTION XV – REGULATORY INFORMATION

---

OSHA/EPA

Not provided.

---

## SECTION XVI – OTHER INFORMATION

---

Basic awareness training on the properties and safe handling of DRI shall be imparted to all handlers those involved in loading, unloading and other operations.

**Disclaimer:** *This Material Safety Data Sheet (MSDS) is provided as an information resource only. Qatar Steel believes that information above is believed to be accurate and represents the best information currently available to us. However, we make no warranty of merchantability or any other warranty, express or implied, with respect to such information, and we assume no liability resulting from its use. Users should make their own investigations to determine the suitability of the information for their particular purposes. In no event shall Qatar Steel be liable for any claims, losses, or damages of any third party or for any special, indirect, incidental, consequential or exemplary damages, howsoever arising.*